

QUICK USER GUIDE

1. Position the ejector in a suitable location.
2. Attach and close the valve on the inlet side of the ejector.
3. Connect a flexible inlet hose from the water source to the ejector (A).
4. Attach a rigid outlet hose to the ejector and place the other end into the filter (B).
5. Turn on the water supply.
6. Pour filter media into the hopper (C).
7. Open the inlet valve on the ejector.
8. Open the flush valve on the ejector (3).
9. That's it!

Scan the QR code
to watch the
how-to-video.

